

GB



Buddy[™] *Arc 145*



Instruction manual



DECLARATION OF CONFORMITY

According to

The Low Voltage Directive 2006/95/EC, entering into force 16 January 2007

The EMC Directive 2004/108/EC, entering into force 20 July 2007

Type of Equipment

Buddy™ Arc 145

Type Designation etc.

Buddy™ Arc 145, Stock code: 0700 300 884, from serial number 01107071701 (2011 wk32)

Brand name or trade mark.

ESAB

Manufacturer or his authorised representative established within the EEA.

Name, address, telephone No, telefax No:

ESAB, Welding Equipment (EPG)
Hanover House,
Queensgate,
Britannia Road,
Waltham Cross,
Hertfordshire
EN8 7TF
Tel:+44 (0) 1992 768515, Fax:+44 (0) 1992 716486

The following harmonised standard in force within the EEA has been used in the design:

EN 60974-1, Arc Welding Equipment - Part 1: Welding Power Sources
EN 60974-10, Arc Welding Equipment - Part 10: Electromagnetic Compatibility (EMC) requirements.

Additional Information: Restrictive use, Class A equipment, intended for use in locations other than residential.

By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorised representative established within the EEA, that the equipment in question complies with the safety requirements stated above.

Date
UK 2011-08-15

Signature

Mr. P. A. Chew
Clarification

Position
Global Director
Enterprise Products Group

10 SAFETY	4
11 INTRODUCTION	6
11.1 Equipment	6
12 TECHNICAL DATA	6
13 INSTALLATION	7
13.1 Location	7
13.2 Mains power supply	7
13.2.1 Recommended fuse sizes and minimum cable area	7
14 OPERATION	8
14.1 Connections	8
14.2 Symbols	8
14.3 Connection of welding and return cable	8
14.4 Overheating protection	9
14.5 MMA welding	9
14.5.1 Striking the arc	9
14.5.2 Manipulation of electrode	9
14.5.3 Anti-electrode pick-up	9
14.5.4 Joint forms	10
14.5.5 Electrode selection	10
15 MAINTENANCE	10
15.1 Power source	11
16 FAULT-TRACING	11
17 ORDERING SPARE PARTS	12
18 DISMANTLING AND SCRAPPING	12
DIAGRAM	13
ORDER NUMBER	14
ACCESSORIES	15

10 SAFETY

Users of ESAB equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the equipment must be familiar with:
 - its operation
 - location of emergency stops
 - its function
 - relevant safety precautions
 - welding and cutting
2. The operator must ensure that:
 - no unauthorised person is stationed within the working area of the equipment when it is started up.
 - no-one is unprotected when the arc is struck
3. The workplace must:
 - be suitable for the purpose
 - be free from drafts
4. Personal safety equipment
 - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves.
 - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns.
5. General precautions
 - Make sure the return cable is connected securely.
 - Work on high voltage equipment **may only be carried out by a qualified electrician.**
 - Appropriate fire extinguishing equipment must be clearly marked and close at hand.
 - Lubrication and maintenance must **not** be carried out on the equipment during operation.



WARNING

Do not use the power source for thawing frozen pipes.



WARNING



Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting. Ask for your employer's safety practices which should be based on manufacturers' hazard data.

ELECTRIC SHOCK - Can kill

- Install and earth the unit in accordance with applicable standards.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from earth and the workpiece.
- Ensure your working stance is safe.

FUMES AND GASES - Can be dangerous to health

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area.

ARC RAYS - Can injure eyes and burn skin.

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

FIRE HAZARD

- Sparks (spatter) can cause fire. Make sure therefore that there are no inflammable materials nearby.

NOISE - Excessive noise can damage hearing

- Protect your ears. Use earmuffs or other hearing protection.
- Warn bystanders of the risk.

MALFUNCTION - Call for expert assistance in the event of malfunction.


Read and understand the instruction manual before installing or operating.

PROTECT YOURSELF AND OTHERS!




CAUTION

Read and understand the instruction manual before installing or operating.



CAUTION

Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.



CAUTION

This product is solely intended for arc welding.



Dispose of electronic equipment at the recycling facility!

In observance of European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.

As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.

ESAB can provide you with all necessary welding protection and accessories.

11 INTRODUCTION

Arc 145 is a general MMA arc welding power source.

ESAB's accessories for the product can be found on page 15.

11.1 Equipment

The power source is supplied with:

- 3 meter welding cable with electrode holder
- 3 meter return cable with return clamp
- instruction manual.

12 TECHNICAL DATA

Arc 145	
Mains voltage	230 V 1~ ± 10%, 50/60 Hz
Primary current I_{max}	27.8 A
Setting range	10 A / 20.4 V - 145 A / 25.8 V
Permissible load at	
15 % duty cycle	145 A / 25.8 V
60 % duty cycle	70 A / 22.8 V
100 % duty cycle	55 A / 22.2 V
Power factor at maximum current	0.76
Efficiency at maximum current	80 %
Open-circuit voltage U₀ max	66 V
Operating temperature	-10 to +40° C
Transportation temperature	-20 to +55° C
Sound pressure at no-load	<70 db (A)
Dimensions l x w x h	280 x 120 x 220 mm
Weight	4.5 kg
Enclosure class	IP 23S
Application class	S

Duty cycle

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 40° C.

Enclosure class

The IP code indicates the enclosure class, i. e. the degree of protection against penetration by solid objects or water. Equipment marked **IP23** is designed for indoor and outdoor use.

Application class

The symbol **S** indicates that the power source is designed for use in areas with increased electrical hazard.

13 INSTALLATION


The installation must be carried out by a professional.

13.1 Location


Position the power source such that its cooling air inlets and outlets are not obstructed.

13.2 Mains power supply

Make sure that the welding power source is connected to the correct supply voltage and that it is protected by the correct fuse rating. The outlet shall have a protective earth connection.



Rating plate with supply connection data



13.2.1 Recommended fuse sizes and minimum cable area

Arc 145	
Mains voltage	230V 1~ ± 10%, 50/60 Hz
Mains cable area mm²	3 G 1.5
Phase current I_{1eff} (TIG)	10.8 A
Phase current I_{1eff} (MMA)	16 A


NOTE! Use the power source in accordance with the relevant national regulations.

14 OPERATION

General safety regulations for handling the equipment can be found on page 4. Read through before you start using the equipment!

14.1 Connections

- | | | | |
|---|--|---|--|
| 1 | Indicating lamp, white, power supply ON | 5 | Connection (+) for return cable or welding cable |
| 2 | Indicating lamp, yellow, overheating | 6 | Connection for mains cable |
| 3 | Knob for setting the welding current | 7 | Mains power supply switch 1/O |
| 4 | Connection (-) for return cable or welding cable | | |



14.2 Symbols



14.3 Connection of welding and return cable

The power source has two outputs, a negative [-] terminal (4) and a positive [+] terminal (5), for connecting welding and return cables.

The output to which the welding cable is connected depends on the type of electrode, please refer to electrode packaging for information relating to the correct electrode polarity.

Connect the return cable to the remaining welding terminal on the power source. Secure the return cable's contact clamp to the work piece and ensure that there is good contact.

14.4 Overheating protection

The welding power source has a thermal overload trip which operates if the temperature becomes too high, interrupting the welding current and lighting a yellow indicating lamp on the front of the power source. The thermal overload trip resets automatically when the temperature has fallen.

14.5 MMA welding

14.5.1 Striking the arc


MMA welding may also be referred to as welding with coated electrodes. Striking the arc melts the electrode, and its coating forms protective slag.

If, when striking the arc, the tip of the electrode is pressed against the metal, it immediately melts and sticks to the metal, rendering continued welding impossible. Therefore, the arc has to be struck in the same way that you would light a match. Quickly strike the electrode against the metal and then raise it to give an appropriate arc length (approx. 2 mm). If the arc is too long, it will crackle and split before finally going out completely. Once the arc has been struck, move the electrode from left to right. The electrode should be at an angle of 60° to the metal.

14.5.2 Manipulation of electrode

In MMA welding, there are three motions to be matched in the end of electrode: the electrode moving to the molten pool along axes [1]; a small oscillation maybe necessary to achieve the desired width of the melt pool [2]; the electrode moving along welding way [3].

The operator can choose the manipulation of electrode based on welding joint sharp, welding position, electrode spec, welding current and operation skill, etc.



1 electrode moving


2 the electrode oscillation (right and left)

3 the electrode move along weld


14.5.3 Anti-electrode pick-up

If, during the welding, the electrode would get in direct contact (touching) with the workpiece to form short circuit, the welding current will drop to a minimum to prolong the life of the electrode.


14.5.4 Joint forms




Butt joint



Corner joint



Lap joint



T joint

14.5.5 Electrode selection

The electrode diameter selection is based on the workpiece thickness, welding position, joint form, welding layer, etc. Please refer to the recommendations on the electrode package for further details.

- To ensure good quality weld, the electrode should always be dried or dry stored. This to avoid hydrogen inclusion, blowholes and cold cracks.
- In the welding process, the arc must not be too long; otherwise, it will cause unstable arc burning, large spatter, light penetration, undercut, blowhole, etc. If the arc is too short, it will cause electrode stick.



15 MAINTENANCE

Regular maintenance is important for safe, reliable operation.

Only those persons who have appropriate electrical knowledge (authorized personnel) may remove the safety plates.



CAUTION

All guarantee undertakings from the supplier cease to apply if the customer attempts any work to rectify any faults in the product during the guarantee period.

15.1 Power source

Check regularly that the welding power source is not clogged with dirt.

How often and which cleaning methods apply depend on:

- welding process
- arc time
- placement
- surrounding environment

It is normally sufficient to blow the power source with dry compressed air (reduced pressure) once a year.

Clogged or blocked air inlets and outlets otherwise result in overheating.

16 FAULT-TRACING

Try these recommended checks and inspections before sending for an authorized service technician.

Type of fault	Corrective action
No arc.	<ul style="list-style-type: none"> • Check that the mains power supply switch is turned on. • Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check to see whether the MCB has tripped.
The welding current is interrupted during welding.	<ul style="list-style-type: none"> • Check whether the thermal cut-outs have tripped (indicated by the orange lamp on the front panel). • Check the mains power supply fuses.
The thermal cut-out trips frequently.	<ul style="list-style-type: none"> • Check to see whether the dust filter is clogged. • Make sure that you are not exceeding the rated data for the power source (i.e. that the unit is not being overloaded).
Poor welding performance.	<ul style="list-style-type: none"> • Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check that the correct electrodes are being used.

17 ORDERING SPARE PARTS

Repair and electrical work should be performed by an authorised ESAB service technician. Use only ESAB original spare and wear parts.


Arc 145 is designed and tested in accordance with the international and European standards EN 60974-1 and EN 60974-10. It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the said standard.

Spare parts may be ordered through your nearest ESAB dealer, see the last page of this publication.

18 DISMANTLING AND SCRAPPING

Welding equipment primarily consists of steel, plastic and non-ferrous metals, and must be handled according to local environmental regulations.

Diagram



Arc 145

Order number





Ordering no.	Denomination	Type
0700 300 884	Welding power source	Buddy™ Arc 145
0459 839 065	Spare parts list	Buddy™ Arc 145

Technical documentation is available on the Internet at www.esab.com

Buddy Arc

Accessories

 A technical drawing of a return cable. It consists of a circular loop of cable with a clamp at the top and a connector at the bottom.	Return cable with clamp 0700 300 863 3 m 16 mm ²
 A technical drawing of a welding cable with an electrode holder. It shows a circular loop of cable with a holder at the top and a connector at the bottom.	Welding cable with electrode holder 0700 300 862

ESAB subsidiaries and representative offices

Europe AUSTRIA ESAB Ges.m.b.H Vienna-Liesing Tel: +43 1 888 25 11 Fax: +43 1 888 25 11 85 BELGIUM S.A. ESAB N.V. Brussels Tel: +32 2 745 11 00 Fax: +32 2 745 11 28 BULGARIA ESAB Kft Representative Office Sofia Tel/Fax: +359 2 974 42 88 THE CZECH REPUBLIC ESAB VAMBERK s.r.o. Vamberk Tel: +420 2 819 40 885 Fax: +420 2 819 40 120 DENMARK Aktieselskabet ESAB Herlev Tel: +45 36 30 01 11 Fax: +45 36 30 40 03 FINLAND ESAB Oy Helsinki Tel: +358 9 547 761 Fax: +358 9 547 77 71 FRANCE ESAB France S.A. Cergy Pontoise Tel: +33 1 30 75 55 00 Fax: +33 1 30 75 55 24 GERMANY ESAB GmbH Solingen Tel: +49 212 298 0 Fax: +49 212 298 218 GREAT BRITAIN ESAB Group (UK) Ltd Waltham Cross Tel: +44 1992 76 85 15 Fax: +44 1992 71 58 03 ESAB Automation Ltd Andover Tel: +44 1264 33 22 33 Fax: +44 1264 33 20 74 HUNGARY ESAB Kft Budapest Tel: +36 1 20 44 182 Fax: +36 1 20 44 186 ITALY ESAB Saldatura S.p.A. Bareggio (Mi) Tel: +39 02 97 96 8.1 Fax: +39 02 97 96 87 01 THE NETHERLANDS ESAB Nederland B.V. Amersfoort Tel: +31 33 422 35 55 Fax: +31 33 422 35 44	NORWAY AS ESAB Larvik Tel: +47 33 12 10 00 Fax: +47 33 11 52 03 POLAND ESAB Sp.zo.o. Katowice Tel: +48 32 351 11 00 Fax: +48 32 351 11 20 PORTUGAL ESAB Lda Lisbon Tel: +351 8 310 960 Fax: +351 1 859 1277 ROMANIA ESAB Romania Trading SRL Bucharest Tel: +40 316 900 600 Fax: +40 316 900 601 RUSSIA LLC ESAB Moscow Tel: +7 (495) 663 20 08 Fax: +7 (495) 663 20 09 SLOVAKIA ESAB Slovakia s.r.o. Bratislava Tel: +421 7 44 88 24 26 Fax: +421 7 44 88 87 41 SPAIN ESAB Ibérica S.A. Alcalá de Henares (MADRID) Tel: +34 91 878 3600 Fax: +34 91 802 3461 SWEDEN ESAB Sverige AB Gothenburg Tel: +46 31 50 95 00 Fax: +46 31 50 92 22 ESAB international AB Gothenburg Tel: +46 31 50 90 00 Fax: +46 31 50 93 60 SWITZERLAND ESAB AG Dietikon Tel: +41 1 741 25 25 Fax: +41 1 740 30 55 UKRAINE ESAB Ukraine LLC Kiev Tel: +38 (044) 501 23 24 Fax: +38 (044) 575 21 88	North and South America ARGENTINA CONARCO Buenos Aires Tel: +54 11 4 753 4039 Fax: +54 11 4 753 6313 BRAZIL ESAB S.A. Contagem-MG Tel: +55 31 2191 4333 Fax: +55 31 2191 4440 CANADA ESAB Group Canada Inc. Mississauga, Ontario Tel: +1 905 670 02 20 Fax: +1 905 670 48 79 MEXICO ESAB Mexico S.A. Monterrey Tel: +52 8 350 5959 Fax: +52 8 350 7554 USA ESAB Welding & Cutting Products Florence, SC Tel: +1 843 669 44 11 Fax: +1 843 664 57 48 Asia/Pacific AUSTRALIA ESAB South Pacific Archerfield BC QLD 4108 Tel: +61 1300 372 228 Fax: +61 7 3711 2328 CHINA Shanghai ESAB A/P Shanghai Tel: +86 21 2326 3000 Fax: +86 21 6566 6622 INDIA ESAB India Ltd Calcutta Tel: +91 33 478 45 17 Fax: +91 33 468 18 80 INDONESIA P.T. ESABindo Pratama Jakarta Tel: +62 21 460 0188 Fax: +62 21 461 2929 JAPAN ESAB Japan Tokyo Tel: +81 45 670 7073 Fax: +81 45 670 7001 MALAYSIA ESAB (Malaysia) Snd Bhd USJ Tel: +603 8023 7835 Fax: +603 8023 0225 SINGAPORE ESAB Asia/Pacific Pte Ltd Singapore Tel: +65 6861 43 22 Fax: +65 6861 31 95	SOUTH KOREA ESAB SeAH Corporation Kyungnam Tel: +82 55 269 8170 Fax: +82 55 289 8864 UNITED ARAB EMIRATES ESAB Middle East FZE Dubai Tel: +971 4 887 21 11 Fax: +971 4 887 22 63 Africa EGYPT ESAB Egypt Dokki-Cairo Tel: +20 2 390 96 69 Fax: +20 2 393 32 13 SOUTH AFRICA ESAB Africa Welding & Cutting Ltd Durbanvill 7570 - Cape Town Tel: +27 (0)21 975 8924 Distributors <i>For addresses and phone numbers to our distributors in other countries, please visit our home page</i> www.esab.com
---	--	--	---



www.esab.com

